



National
Metrology
Institute



Proficiency Test

Gas analysis: Stack Gas (NO, SO₂, CO, CO₂, C₃H₈)

Many laboratories participate in Proficiency Tests (PT schemes) or interlaboratory comparisons (ILC). Measurement results from multiple laboratories are anonymously compared with each other to identify any deviations. The results will give you valuable insights into your laboratory's performance, ensure and even increase your quality, can be used as a reliable tool for quality and risk management and will meet the requirements of various accreditations and ISO/IEC 17025:2017.

VSL organizes PTs under the ISO/IEC 17043:2010 accreditation with the highest care. When organizing any PT, VSL will:

- provide a suitable artifact;
- compose a test protocol;
- deliver an independent assessment report;
- provide anonymous comparison of results;
- offer metrological and quality management support at request.

Selection of participants:

Available for laboratories working with international standards (e.g. ASTM D1945, GPA 2261, GPA 2286, ISO 6974, ISO 6976, ISO 17023) and all in house methods for stack gas composition measurements.

Registration:

Please go to our website www.vsl.nl/en/services/proficiency-testing to fill in the registration form.

Fee:

€ 7.000,00 (excluding transport and VAT)

Transport

€ 250,00 (Benelux)

€ 500,00 (EU)

On request (outside EU)

Terms of payment:

Payment in advance. Invoice will be sent 1 month before the start of the PT. Payment is due within 30 days after invoice date.

Schedule:

The up-to-date PT schedule can be found on our website.

About VSL

VSL, the National Metrology Institute for The Netherlands, is a globally accredited PT provider (ISO/IEC 17043:2010, our scope reg. nr. R006).

Our independent comparisons covers a broad range of areas including pressure, mass, viscosity, temperature, electricity, length, chemical analysis, humidity and gas flow. Customers also ask VSL for advice and implementation of custom comparisons. We encompass all calibration capabilities across various technological fields listed in our extensive ISO/IEC 17025:2017 accredited calibration scope (reg.nr. K999) and our ISO 17034:2016 scope (reg. nr. P002).



For more information on VSL and our offerings, please visit our website at www.vsl.nl/en/services/proficiency-testing. Should you have any questions or wish to join our PTs, feel free to contact us.



Estimated number of participants:

Minimal 5 participants, maximal 15 participants

VSL reserves the right to cancel the PT in case the number of participants is smaller than anticipated. In that case, VSL will contact you to find a suitable solution.

Reference laboratory:

The reference values for this PT will be delivered by VSL, the National Metrology Institute for the Netherlands.

Measurements protocol:

VSL will provide the protocol before the shipment of the cylinders.

Each participant will have 3 weeks to perform the calibration.

Evaluation:

For qualification of the participant results, Z-scores and E_n -numbers are calculated. Both are a measure for the relative distance from the reference value. In the calculation of the E_n -number the uncertainty stated by the participant is incorporated.

The Z-score is defined as:
$$Z_i = \frac{x_i - X_{ref,i}}{s_R}$$

The E_n -number is calculated according to:
$$E_n = \frac{x_i - X_{ref,i}}{\sqrt{U_{ref,i}^2 + U_{stat,i}^2}}$$

Confidentiality statement:

VSL keeps all data regarding the performance of individual participants, or groups of participants, strictly confidential. Data is accordingly protected and stored in areas on networks with restricted access. The relationship between results and the laboratories that submitted them will never be disclosed. Only the laboratory is granted access to its performance through the assigned code number.

Deliverables:

VSL will provide a stack gas sample for analysis and will deliver a test report including the anonymized measurement results of the comparison.

VSL

Thijsseweg 11
2629 JA Delft
The Netherlands
T +31 (0)15 269 15 00
E vsl@vsl.nl
W www.vsl.nl

CoC: 27.228.703
TAX: NL800189620B01
IBAN: NL24ABNA0620273321

Information about the artifact to be used:

Stack gas mixture, provided in a 5L aluminum cylinder with DIN 447-1 connection.

Stack gas composition range:

Component	Range (% mol/mol)
CO	10 - 1000 PPM
CO ₂	1 - 20 %
NO	10 - 1000 PPM
SO ₂	10 - 1000 PPM
C ₃ H ₈	3 - 100 PPM
N ₂	Matrix

VSL

Thijsseweg 11
2629 JA Delft
The Netherlands
T +31 (0)15 269 15 00
E vsl@vsl.nl
W www.vsl.nl

CoC: 27.228.703
TAX: NL800189620B01
IBAN: NL24ABNA0620273321